

UNISEN 联力胜利

iPazzPort 艾拍宝


Mini Keyboard


迷你键盘


instructions


使用指南








 **FN+Space**  
Adjust sensitivity of the touchpad


 the browser home page


 stop


 mute

 left mouse

 back


 searching


 Menu

 right mouse



**Power Switch**

 **FN+F6** Lock/Unlock keyboard and touchpad

 **FN+F8** Turn on/off click function of mouse touchpad

 **Mouse touchpad**

**Introduction:**

- PC Keyboard for Home entertainment, multi-media Education, Training, Conference, presentation controlled with computer.
- Perfect for Pad, Andriod TV Box, Google TV Box, Xbox360, PS3, HTPC/IPTV

**Package:**

- |                 |   |
|-----------------|---|
| - Mini Keyboard | 1 |
| - User manual   | 1 |
| - USB cable     | 1 |

**Feature:**

- Portable and handheld size
- Full QWERTY keyboard
- Ultra-sensitive mouse touchpad
- Supports multi-touch gesture and Scrolling bar
- Supports multi language (need to be customized)

**Specifications:**


- Wireless connection
- Max Distance: 10 m
- Size: 147X99.5X21.6mm
- Weight: 110g
- Transmit power: +5db Max
- Operation voltage: 3.3V
- Power Supply: Two version for choosing
  - a. 1.5V 3A Battery x2
  - b. Rechargeable Li-ion battery

**System Requirement:**

- Windows
- Mac OS
- Linux
- Android/Google/Smart TV

## 6. How to use

### 6.1. Start up



1. Open the battery cover,  
take USB dongle out

4. The connection is successful!

(slide your finger on touchpad you can feel the touch or moving on the screen )



2. Plug USB dongle into any  
USB port of your device  
(Raspberry Pi/Smart TV /PC)



Power Switch

3. Turn the unit on by switching the power switch  
down (the LED would be flashing then go out )







6.2. Pair: in case of lose connection between USB dongle and keyboard, please follow below steps to do re-pair procedure:

6.2.1. Press button "Fn" and "⌂" at the same time till LED flash;

6.2.2. Plug USB dongle into any USB port of your computer;

6.2.3. Approach mini keyboard to the USB dongle and LED off means re-pair is successful.

6.3. Recharge your keyboard: when your keyboard  flashing without any operation that means your keyboard is in low charge, and need to recharge. Connect your keyboard to your computer with mini end of USB cable to your keyboard and another end to computer, then  will light up with steady on, and go out when it is fully recharged.



6.4. To avoid the RF-signal blocked by TV metal case Please use the supplied extend USB cable

---

**Note: Work with Raspberry Pi/Smart TV:**


**1.How to use:**

**1.1. Open the battery cover, take out the USB dongle**

**1.2 .Plug USB dongle into device USB port.**

**1.3. Before connection established ,it will take seconds to install driver by USB dongle itself.**

**2.If still can't work or lost connection in using, Please do re-pair procedure as following**






**2.1. Charge battery for one hour and press FN+ simultaneously till LED flash**

**2.2. Plug the USB dongle into device USB port and put the keyboard closer to the USB dongle**

**2.3. LED off means re-pair procedure is complete successfully.**

**Multi-touch application:**

the touchpad supports various gesture, the related gesture and function is described below:

Touchpad Function	Mouse Function	Finger Gesture	Finger Action	Remark
Moving	Move Cursor		Slide one finger on the touchpad	
Middle botton click	Middle botton click		Tap the touchpad with two finger simultaneously	 ▲ Scroll upward ▼ Scroll downward Scroll pages quickly when browse website
Vertical two finger scroll	Scroll middle key		Slide two finger vertically	Zoom in or out the picture when view pictures
Right click	Right button click		Tap the touchpad with three fingers simultaneously	

## **FAQ:**

**1. How to connect it with Smart TV/Raspberry Pi (Windows/Android System):**

The same way as above one

**2.Touchpad become unstable /insensitive or type the letter, they are stuck on the screen.**

Charge battery for several hours.

**3.No response or need to press several times from a long distance.**

To avoid the RF-signal blocked by TV metal case  
Please use the supplied extend USB cable

**4.The multi media keys can't work**

Update player version or install relevant driver.  
It's same with Logitech

**5. Other needs beyond above query, please contact us with below email to get support.**

Email:[sales@unisenonline.com.cn](mailto:sales@unisenonline.com.cn)

All questions would be answered within 24 hours.  
One Year Limited Warranty From iPazzPort



### WEEE Directive & Product Disposal:



At the end of its serviceable life, this product should not be treated as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.

### Notice to customers



This symbol on the battery indicates that the battery is to be collected separately. The following applies only to users in European countries.

This battery is designed for separate collection at an appropriate collection point. Do not dispose of as household waste.

For more information, contact the retailer or local authorities in charge of waste management.

### Caution :

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### 应用

- 无线键盘应用于家庭娱乐、教育、培训、会议、演讲和投影仪
- Windows/Mac 电脑、智能电视、机顶盒

### 包装清单

- |          |   |
|----------|---|
| - 迷你键盘   | 1 |
| - 说明书    | 1 |
| - USB充电线 | 1 |

### 特征

- 微型外形,方便携带
- QWERTY全键盘布局
- 支持多种手势和滚动条
- 支持多国语言(需要定制)


### 支持系统

- Windows
- Mac OS
- Linux
- Android/Google/Smart TV

### 规格

- RF2.4G无线连接
- 距离: 最大半径10m
- USB连接, 即插即用
- 电源: 1.5V X AAA 2节 (或者锂电池)
- 工作电压:3.3V
- 无线发射功率: 2dBm
- 接收灵敏度: -85dBm
- 尺寸: 147X99.5X21.6mm
- 重量: 110g

### 开机



1. 打开电池盖, 拿出接收器



2. 将接收器插入你的设备上的USB接口处

3. 插好接收器后, 打开电源开关

## 配对

同时按下Fn键+无线键LED灯闪烁,此时将接收器插到电脑或Android设备USB接口上,LED停止闪烁,表示配对成功.

注意:键盘出厂已配对好,不必重新配对.

## 充电



当键盘未进行任何操作时,指示灯突然闪烁,说明键盘要进行充电,用USB线将键盘与电脑连接好,红色指示灯会亮起来,在充电过程中,指示灯会长亮.当键盘电充满时指示灯熄灭,此时将USB线从电脑上拔下来.



## 键盘功能描述



电源开关



多点触摸应用:

多点触摸应用说明如下图:

触摸功能	等效鼠标功能	图示	图示描述	备注
移动	移动鼠标光标		在触摸板上滑动手指	
中键单击	中键单击		同时用两个手指在触摸板上单击	浏览网页时双指单击会出现滚动条，将光标向上快速移动至该图上方，反之则向下
两手指垂直方向移动	滚动鼠标中键		两手指垂直方向移动	浏览图片时，两手指向上、下移动可以放大或缩小画面
右击	鼠标右击		三个手指同时单击	



## 常见问题解答

1. 触摸板不灵敏,或输入字体卡在屏幕  
请将电池充满电,然后重启键盘
2. 远距离操作没有反应或者要按几次按钮才有反应.  
电视机金属外壳会阻挡无线信号,请将接收器插入我们提供的USB延长线上使用.
3. 多媒体按键没有反应  
请更新你的播放器版本或者下载安装相关驱动程序
4. 其他需求或帮助请发邮件至:  
**[sales@unisenonline.com.cn](mailto:sales@unisenonline.com.cn)**,