


LED Digital Clock Instructions

Application: DS-6609

Main Functions

- Two display modes: 1). Display time only; 2). Time, Date, Temperature cycle display
- Brightness mode adjustable: 1). Three levels of automatic sensitivity; 2). Three levels of manual brightness adjustment;
3). Can turn off the display; 4). Four levels of sensitive in sleep mode
- Memory mode: 1). Install the battery 2032, no power memory go away;
- Alarm functions: 1). Snooze Mode; 2). Single/double weekend/daily alarm

Do not block the sensor window




The name and function of each part

- ① "SET": for comprehensive settings
- ② "+": setting mode - upgrading; non-setting mode - tap to adjust brightness, press and hold (3 secs) the button to switch display mode
- ③ ".": setting mode - down; non-setting mode - tap to turn on / off alarm clock, press and hold (3 secs) the button to enter the alarm clock setting mode

Long press mentioned in the text means that holding for 3 secs

Comprehensive Settings

1. General setting:




2. Display mode setting: Long press "+" to switch display mode:

- Display time only; 2). Time, Date, Temperature cycle display
- Brightness mode setting: Tap "+", "L-SL" four speed sensitive in sleep mode;
"L-RU" three levels of automatic sensitivity; "L-01" first brightness; "L-02" second brightness; "L-03" third brightness; turn off the display, such a cycle operation.

Alarm Settings

1. Switch alarm clock: tap "-" (correspond "⊖" shortcut icon) to open/close alarm, display the alarm clock that has been set for 3 seconds when open; at the same time, the alarm indicator of the corresponding group lights up; turn off the alarm and the corresponding alarm indicator turns off.

2. Set alarm clock: long press "-", enter alarm setting, distinguish 12/24H



3. Start snooze:

when the alarm clock rings, tap any key to start snooze, alarm indicator light flashes slowly

4. Turn off the alarm:


when the alarm clock rings, long press any key to turn off alarm, enter the next alarm state

LED数字钟说明书

适用于：DS-6609


主要功能

- ①、两种显示模式：1、只显示时间。2、时间、日期、温度循环显示。
 - ②、亮度模式可调：1、三档自动感光；2、三档手动亮度调整；3、可关闭显示；4、睡眠模式四档感光。
 - ③、记忆模式：1、装上2032电池，无电源记忆走时。2、无电池及电源情况下，记住最近一次的时钟及各种设置模式。
 - ④、闹铃功能：带贪睡模式和单/双休/每天闹铃。



综合设置


1. 常规设置 ·



- 2.显示模式设置：长按“ \oplus ”键切换显示模式；①只显示时间；②时间、日期、温度循环显示。
3.亮度模式设置：短按“ \oplus ”键，“ $L-5L$ ”带睡眠模式自动感光(四档亮度)；“ $L-AU$ ”自动感光(三档亮度)；“ $L-O1$ ”(一档亮度)；“ $L-O2$ ”(二档亮度)；“ $L-O3$ ”(三档亮度)；关闭显示，如此循环操作。

闹钟设置

1. 开关闹钟：短按“ \ominus ”键(对应“”快捷图标)打开/关闭闹钟，打开时显示3秒已设定的闹钟时间，同时对应组的闹钟指示灯亮起；关闭闹钟则对应的指示灯关闭。
 2. 设置闹钟：长按“ \ominus ”键，分别进入闹钟设定。区分12/24H制



- 3.启动贪睡：当闹钟响起，短按任意键开启贪睡模式，闹钟指示灯慢闪。
4.关闭闹钟：当闹钟响起，长按任意键关闭本次闹钟，进入下次闹钟状态。